

Farécla

RSG
Refinish Solutions Group

Spot-On Defect Removal

The ideal solution to remove dust nibs quickly and easily. This kit includes everything a technician needs to properly perform small spot repairs in a convenient tool bag.



Farécla Spot Repair Kit

This kit includes the best solutions essential to quickly and efficiently complete a small spot repair.

Kit Part# 66623391491

PART #	DESCRIPTION	GRIT/COLOR/SIZE	QTY	BRAND
662611 47433	3" Black Ice NorGrip Disc	2000 grit	50	Norton
776960 88704	3" Pure Ice Q175 Fine Film Finishing Disc	1500 grit	50	Norton
662611 47432	3" Black Ice NorGrip Disc	2500 grit	50	Norton
636425 05457	3" NorGrip Foam Interface Pad (thin)	1/2" thick	1	Norton
-	3" Sander Tool	Beige/Black	1	Hutchins
-	3" M12 Variable Speed Polisher (includes battery and charger)	Red	1	Milwaukee



PART #	DESCRIPTION	GRIT/COLOR/SIZE	QTY	BRAND
666233 91319	3.5" Single-Sided CCS Waffle Cutting Foam Pad	Orange	1	Farécla
666233 91321	3.5" Single-Sided CCS Waffle Finishing Foam Pad	Blue	1	Farécla
666233 90600	G360 Super-Fast Compound	500mL	1	Farécla
666233 90601	G360 Super-Fast Finish	500mL	1	Farécla
666233 91496	Detail Microfiber Towel	Grey	1	Farécla
666233 91497	All-Purpose Microfiber	Blue	1	Farécla

DUST NIB REMOVAL WITH YOUR SPOT REPAIR KIT

SANDING: STANDARD SIZE

1. Mist water on area to saturate the defect.
2. Wet sand the area with 3" Norton Black Ice NorGrip disc in 2000 grit and the 3" NorGrip foam interface pad. Sand until the defect is removed.
3. Wipe area completely dry with the Farécla all-purpose microfiber cloth, and inspect if defect is removed.
4. Repeat step 2 and 3 if needed.

SANDING: LARGER AREA REMOVAL

1. Sand area with 3" Norton Pure Ice Q175 Fine Film Finishing disc in 1500 grit and 3" NorGrip foam interface pad until the defect is removed.
2. Wipe using the Farécla all-purpose microfiber cloth to remove dust and inspect the area.
3. Repeat steps 1 and 2 if needed.
4. Mist a coating of water on previously sanded area.
5. Wet sand the area with 3" Norton Black Ice NorGrip disc in 2500 grit and NorGrip foam interface pad until the area looks uniform.
6. Wipe area dry with the Farécla all-purpose microfiber cloth.
7. Repeat steps 5 and 6 as needed until all sanding imperfections are removed.



STANDARD OPERATING PROCEDURE

POLISHING:

1. Dispense a pea-size amount of Farécla G360 Super-Fast Compound onto the defect area. Buff using 3.5" single-sided Farécla CCS waffle cutting foam pad on the Milwaukee polisher, set to speed 1. Polish until all sand marks are removed.
2. Use the Farécla detail microfiber towel to remove any residue.
- 3. FOR DARK COLORS ONLY**
Use Farécla G360 Super-Fast Finish and 3.5" single-sided Farécla CCS waffle finishing foam pad on the Milwaukee polisher set to speed 1. Polish until all haze is removed.
4. Use the Farécla detail microfiber towel to remove any left-over residue.



An Initiative of Saint-Gobain

www.refinishsolutionsgroup.com | 1 (800) 456-8444 | Email: rsg@saint-gobain.com

FORM #8941 REV. 02/22

© Saint-Gobain February 2022.

Carborundum, Black Ice, Farécla, NorGrip, Norton, Pure Ice, Solar Gard, and "Refinish Solutions Group" are trademarks of Saint-Gobain Abrasives. M12 is a trademark of Milwaukee. All other trademarks are the property of their respective owners.